



Product Description

The Scotch-Brite™ Easy Erasing Pad 4004 is an effective cleaning tool that is used to remove marks and stains from various surfaces. It consists of a white polymeric foam cleaning pad bonded to a blue urethane foam sponge pad.

Special Features

- Trademarked bow-tie shape.
- Soft, flexible pad cleans many surfaces without using additional chemicals - just use water.
- Blue urethane foam sponge holds water to keep pad moist, can be used to wipe after use, and keeps the pad intact over its useful life.
- Pad will not scratch glass, ceramic tile, fiberglass, porcelain, Formica®, metal, Corian®, marble, stainless steel, plastic, vinyl, and most wall coatings.
- Optimal performance of product is achieved when used with water alone. Detergents and sanitizing cleaners are not recommended for use with this product.

Applications:

The Scotch-Brite™ Easy Erasing Pad 4004 is versatile enough to use in Health Care, Education, Commercial Buildings and Food Service for a variety of surfaces and marks.

Surfaces:

- White boards
- Sports equipment
- Countertops
- Flat painted surfaces
- Tables, chairs, and walls
- Stainless Steel
- Hard and textured surfaces
- Vinyl seating
- Restaurant plates - metal marks
- Sneeze guards in food buffets
- Restaurant play area and equipment

Quick Links

[Food Service Website](#)
[Safety Data Sheets \(SDS\)](#)

Some of these links lead to web-based resources that are not product-specific.

Mark Types:

- Dried food grease
- Metal marking
- Food and beverage stains
- Hard water spots
- Soap scum
- Crayon, pen, pencil marks
- Scuff marks
- Graffiti
- Tape adhesives residues
- Lipsticks
- Wax
- Paint and plastic residues

General Use Directions

1. Rinse under tap water and squeeze out any excess water.
2. Using the white side of the pad, wipe away marks and stains using moderate pressure.
3. If needed, use blue side of the pad to wipe away any residue from surface.
4. Rinse pad after use, if needed.
5. Discard pad after multiple uses when white foam has worn away.

(Typical Values)

Composition: (by volume) 50% polymeric foam, 50% urethane foam

Size:

Length: 4.5 inches

Width: 2.8 inches

Color: White polymeric foam
Blue urethane foam

Shape: Bow-tie

Precautionary Summary:

- The Scotch-Brite™ Easy Erasing Pad 4004 may dull glossy, plastics, or other soft surfaces, and may change the appearance of some painted surfaces. Test in an inconspicuous area using light pressure before use on these surfaces.
- The pad should be wet before use. This helps cleaning performance, prevents dust formation, and increases the durability of the pad.
- Chemicals are not recommended for use with this pad, however, most chemicals will not affect the performance or appearance of the pad.
- The pad will not remove all marks, especially on non-porous surfaces.
- The polymeric side of the pad may absorb and/or transfer some pigments.
- The Scotch-Brite™ Easy Erasing Pad 4004 is not itself an eye, skin, or inhalation irritant. However, if it is used with any chemicals, follow precautionary statements for that product.

KEEP OUT OF THE REACH OF CHILDREN.

Health and Safety

When handling any chemical products, read the manufacturers' container labels and the Safety Data Sheets (SDS) for important health, safety and environmental information. To obtain SDS sheets for 3M products go to 3M.com/SDS, or by mail or in case of an emergency, call 1-888-364-3577 or 1-651-737-6501. When using any equipment, always follow the manufacturers' instructions for safe operation.

Technical Information

Technical information and data, recommendations, and other statements provided by 3M are based on information, tests, or experience which 3M believes to be reliable, but the accuracy or completeness of such information is not guaranteed. Such technical information and data are intended for persons with knowledge and technical skills sufficient to assess and apply their own informed judgment to the information. The typical values shown should not be used for the purpose of specification limits. If you have questions about this Product, contact the **Customer Service Department at 1-800-852-9722.**

Product Use

Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. Given the variety of factors that can affect the use and performance of a 3M product, user is solely responsible for evaluating the 3M product and determining whether it is fit for a particular purpose and suitable for user's method of application.

Warranty

3M warrants that each 3M product will be free from defects in material and manufacture for 90 days from the date of purchase from 3M's authorized distributor. 3M MAKES NO OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Limited Remedy

If a 3M product does not conform to this warranty, the sole and exclusive remedy is, at 3M's option, replacement of the 3M product or refund of the purchase price.

No Extension of Warranty

In the case of an approved warranty claim, the replacement Product will carry only the remaining term of the original warranty period.

Limitation of Liability

Except where prohibited by law, 3M will not be liable for any loss or damage arising from the 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted.

Commercial Solutions

3M Center, Building 220-12E-04
St. Paul, MN 55144

1-800-328-0033
3M.com/Foodservice

© 3M 2019. All rights reserved.
3M, Scotch-Brite and the shape of the easy erasing pad are trademarks of 3M.
Used under license in Canada.
All other trademarks are property of their respective owners.
Revision B, September 2019 Please recycle.

3M Science.
Applied to Life.™